

YOSHIMURA

RESEARCH&DEVELOPMENT OF AMERICA, INC.

5420 DANIELS STREET STE A, CHINO CA., 91710 · (800)634-9166 · (909)628-4722 · FACSIMILE (909)591-2198

www.yoshimura-rd.com

YOSHIMURA PERFORMANCE EXHAUST SYSTEM

SUZUKI 2008-2010 GSX 650 F

1155272	TRC SLIP-ON SYSTEM WITH CARBON FIBER SLEEVE
1155275	TRC SLIP-ON SYSTEM WITH STAINLESS STEEL SLEEVE
1155277	TRC SLIP-ON SYSTEM WITH TITANIUM SLEEVE



THIS PRODUCT IS DESIGNED FOR USE IN CLOSED COURSE RACING AND IS NOT INTENDED FOR HIGHWAY USE.



Installation Procedures:

Page 2

Caution: Exhaust system can be extremely hot. Let motorcycle cool

down before beginning installation.

Note: Read through all instructions before beginning installation.

Tools Needed:

Metric Socket Set 3/8" Ratchet and Extension Metric Combination Wrench Set Metric Allen Wrench Set Torque Wrench Power Drill 13/64" Drill Bit

Installation Steps:

1 Remove the stock muffler, heat shield, and muffler gasket (see Fig. 1 for bolt locations).

NOTE: Stock muffler gasket will not be used with Yoshimura slip-on system.

- 2 Install rubber heat insulator to the inside of the Yoshimura muffler clamp and slide Yoshimura muffler clamp over the Yoshimura muffler.
- 3 Slide the supplied exhaust clamp over the inlet of the Yoshimura tailpipe.
- 4 Slide the Yoshimura tailpipe and muffler onto the stock underbelly muffler.
- 5 Mount Yoshimura muffler clamp to the inside of the stock muffler bracket using the stock bolt, washers, and nut (see Fig. 2).

NOTE: Hand tighten only at this point.




Fig. 1



Fig. 2


- 6 Standing at the back of the motorcycle, check for proper alignment of the muffler. Adjust if necessary.
 - NOTE: To adjust fitment, it may be necessary to rotate the tailpipe or the muffler independently until proper alignment of the muffler is achieved.
 - NOTE: We will be installing a securing rivet into the tailpipe to prevent the tailpipe from rotating while the motorcycle is in operation.
- 7 Drill a 13/64" hole through the outlet of the stock underbelly muffler, using the securing hole located near the Yoshimura tailpipe inlet as your guide (See Figure 2).
 - CAUTION: Always wear eye protection when using any power tools.
- 8 Insert securing rivet into drilled hole, slide supplied stainless steel collector clamp over rivet and torque clamp to 1.25 kg-m (9 lb-ft).
- 9 Torque muffler clamp bolt to 2.5 kg-m (18 lb-ft).
- 10 It is recommended that the muffler and tailpipe be wiped down with rubbing alcohol to remove oil and fingerprints. This will help prevent tarnishing of the finish after the exhaust is heated up.
- 11 Check for proper clearance between new exhaust system and motorcycle (i.e. swing-arm, body work, etc.). If any problem is found, please carefully follow through the installation steps again. If problem still persists, please call Yoshimura technical department at (800)634-9166 / in CA (909)628-4722.

NOTE: After starting motorcycle, it is normal for a new exhaust system and muffler to smoke until oil residue burns off.



Part List: Page 4

#115527(2,5,7)



Parts Diagram

NO.	DESCRIPTION	QTY	PART #
1	Stainless Steel Exhaust Clamp	1	20063
2	Yoshimura Slip-On Tailpipe	1	1155-435
3	Medium Exhaust Springs	2	RACE-SPS-1
4	Yoshimura Race Muffler	1	
	with Carbon Fiber Sleeve		CRTRC166W
	with Stainless Steel Sleeve		SRTRC166W
	with Titanium Sleeve		TRTRC166W
5	Yoshimura Muffler Clamp	1	
	for use with Carbon Fiber Sleeve		CTS082
	for use with Stainless Steel or Titanium Sleeve		CTS082X
6	Heat Shield Bolt	2	RC116HSB
7	Heat Shield	1	1155-HS
8	Securing Rivet	1	S-RIVET
**	Rubber Heat Insulator	1	HT SHLDTRS
**	Yoshimura Spring Puller Tool	1	ST-200
**	Yoshimura Vinyl Sticker	1	17029