

WOODCRAFT

60-0250R Cover Protector Installation Instructions

1) Remove the three bolts from the OEM cover as shown in the diagram at the right.

2) Attach the skid plate to the Woodcraft cover by bolting it from the inside.

IMPORTANT - USE THREADLOCKING COMPOUND ON THE THREE SKID PLATE MOUNTING BOLTS

3) Install the Woodcraft cover over the OEM Suzuki cover with the included Woodcraft mounting hardware. The longest bolt goes in the #1 hole and the shortest bolt goes in the #3 hole.

4) Start the motorcycle and inspect for any leaks before riding.



WOODCRAFT

60-0250R Cover Protector Installation Instructions

1) Remove the three bolts from the OEM cover as shown in the diagram at the right.

2) Attach the skid plate to the Woodcraft cover by bolting it from the inside.

IMPORTANT - USE THREADLOCKING COMPOUND ON THE THREE SKID PLATE MOUNTING BOLTS

3) Install the Woodcraft cover over the OEM Suzuki cover with the included Woodcraft mounting hardware. The longest bolt goes in the #1 hole and the shortest bolt goes in the #3 hole.

4) Start the motorcycle and inspect for any leaks before riding.



WOODCRAFT

60-0250R Cover Protector Installation Instructions

1) Remove the three bolts from the OEM cover as shown in the diagram at the right.

2) Attach the skid plate to the Woodcraft cover by bolting it from the inside.

IMPORTANT - USE THREADLOCKING COMPOUND ON THE THREE SKID PLATE MOUNTING BOLTS

3) Install the Woodcraft cover over the OEM Suzuki cover with the included Woodcraft mounting hardware. The longest bolt goes in the #1 hole and the shortest bolt goes in the #3 hole.

4) Start the motorcycle and inspect for any leaks before riding.

