

Mounting Instructions for mounting 2010 Wolfman and Backroads Moto
Side Racks
BMW 800-650 Twin

This kit contains the following:

Quantity	Description
1	Left rack
1	Right rack
6	8mmx20mm hex head
8	8mm flat washers
2	8mmx45mm socket head
2	5/8x1 1/4 spacers

Tools needed

BLUE or a Medium Strength Locktight or thread locker

13mm end wrench or socket and ratchet

45T torx

6mm hex key

These Racks are intended to be used only with the Wolfman Expedition Dry Saddlebags and Teton Saddlebags.

Read and understand these instructions before touching your bike, rack or a wrench

Be Sure To Locktight All Bolt's

Right side rack

1. Remove seat.
2. Position rack in place, place locktight and One 8mm washer on a 8mmx45mm socket headed bolt and start.(do not tighten at this time) SEE FIG1

FIG 1



FIG 2



3. Place locktight and one 8mm washer on a 8mmx20mm hex bolt and start. (do not tighten at this time) SEE FIG 2
4. Place locktight and one 8mm washer on two 8mmx20mm hex bolts and install in the lower mount. SEE FIG 3

FIG 3



5. Tighten all bolts on right side.

FIG 4



Left side rack

1. Remove exhaust muffler.
2. Position rack in place, place locktight and One 8mm washer on a 8mmx45mm socket headed bolt and start.(do not tighten at this time) SEE FIG1
3. Place locktight and one 8mm washer on a 8mmx20mm hex bolt and start. (do not tighten at this time) SEE FIG 2
4. Place locktight and one 8mm washer on two 8mmx20mm hex bolts and install in the lower mount. SEE FIG 4
5. Tighten all bolts on left side.
6. Reinstall muffler and seat.



If you have any questions call or email Berg Briggs at:
1-307-690-0452
berg@brmoto.com