

## **ASSEMBLY INSTRUCTIONS**

048-0960

REVISION A

10/01/19

PAGE I

## RSD BELT GUARD INSTALLATION

- I. Turn your motorcycle off, place securely on a lift or side stand.
- 2. Remove the factory sprocket cover. Note: Some components such as exhaust and brackets may need to be removed, Consult your HD service manual for specific instructions.
- 3. Use medium strength thread locker on the supplied I/4-20 and 3/8-16 socket head bolts.





4. Install the RSD Belt guard using the supplied spacers. Torque the 3/8-16 bolt to 30-33 ft-lbs and the 1/4-20 bolt to 80-120 in-lbs.





- 5. Reinstall any components that were removed. Install the RSD countershaft pulley cover 0217-2007 (Sold separately) to complete the tracker look.
- 6. Hit the road.



PRODUCT DESCRIPTION

RSD BELT GUARD ASSEMBLY: 2004 AND UP XL SPORTSTER (EXCEPT XRI200R)

0217-2006