



INSTALLATION INSTRUCTIONS: BROUHARD 5 HOLE POINTS COVER

Part #'s : LF-0014-B, LF-0014- C, WF-0014-B, WF-0014- C

KIT INCLUDES: 1 points cover, 5 8/32X1/2" stainless bolts

Do not attempt to fit parts to motorcycle unless properly trained. Incorrect fitment may result in injury or death.



1. Remove stock cover using a T20 Torx. Set aside.



2. Using the supplied hardware and blue Loc-Tite, install the Brouhard points cover using a 9/64 inch allen wrench for Lefty series and a 3/32 inch allen wrench for Waterfall series. Torque to factory specs.



3. ENJOY!

Thank you for purchasing a Brouhard designed product. Extreme care has gone into the design and production. Should you not be 100% satisfied or have any questions, please email us at brouharddesigns@yahoo.com