

# **V-ROD Taillight Installation Instructions:**

**Parts Needed:** Philips Head Screwdriver

- 1) Remove Stock Taillight By inserting a Philips head screwdriver into the access hole at the bottom of the fender. Push up on release tab and pull taillight out of fender.
- 2) Unplug Amp connector at taillight housing base on fender of bike.
- 3) Be sure taillight base is clean and free of debris, gasket will need to make a clean contact with the base.
- 4) Plug Amp connector from new LED taillight into housing base on fender of bike, be sure connector snaps into place.
- 5) Snap LED Taillight into place.
- 6) Check operation of LED taillight in both running and brake modes.

**Disclaimer:** Custom Dynamics LLC assumes no liability of any kind as a result of conversations or additions to your vehicle.

