



Mounting Suggestions

Harley-Davidson® Sportster 2004 - 2013

Solo Seat

- Tools Required:
- Phillips Screwdriver
 - Allen Wrench Set

- Hardware:
- Stock 1/4-20 Rear Fender Screw
 - Fender Nut Kit (Included)

Baseplate Features:

The baseplate is made of marine-grade fiberglass, 3/16" thick, finished in high gloss gel coat. Polyurethane rubber bumpers prevent it from touching the frame and fender and minimize vibration.



Stock Seat Removal Steps

1. Remove the rear fender screw and set aside. The stock rear fender screw will be used to attach your new Mustang Solo Seat.
2. Lift back of seat up about 1" then push seat forward until the slotted center of the seat releases from the frame's shoulder bolt. (Fig. I)

Fig. I



Mounting of Mustang Seat

1. Install supplied fender nut kit into the hole in (or "on top of") of the fender.
2. Engage nose bracket into the frame at the base of the fuel tank, just like the stock seat. (Fig. II)
3. Secure the back of the solo seat to the fender with stock fender screw to complete the installation process. (Fig. III)

Fig. II



Enjoy the Comfort of your new Mustang Seat!



Fig. III



These steps are guidelines to help you install your new Mustang product. If you need further assistance please call us at 800-243-1392, Monday through Friday 9:00 - 5:30 Eastern or send an e-mail to questions@mustangseats.com or visit our website at www.mustangseats.com.

For care and maintenance of our seats, please go to our website under "Support".

Refers to part number: 79427, 79429, 79437, 79439, 76157, 76159, 76148, 76150, 76151, 76153, 76568, 76570, 75540, 75541, 76154, 76156