



Kawasaki Radiator Braces
Installation Instructions
#1901-0175 '08 KLX 450

- 1) Remove radiator shrouds, and plastic louvers
- 2) Drain radiator coolant, by removing the radiator cap and then the coolant drain plug on the side of the water pump (Fig 1)
- 3) Reinstall coolant drain plug
- 4) Loosen the hose clamps on the radiators, then pull the hoses off the radiators.
- 5) Remove the 4 bolts holding the radiators to the frame and remove radiators from the bike.
- 6) Install upper and lower support rods on the left radiator brace using 2 of the supplied 6 x 16 mm bolts.
- 7) Place the brace marked with an L on the back of the Left radiator (Fig 2)
- 8) Using the 2 of the supplied 6 x 30 mm bolts along with 2 of the supplied 6 x 22mm washers plus the stock washers, re-attach the left radiator with brace to the bike. (Fig 3 & 4)
- 9) Using 2 of the supplied 6x8mm bolts install the smaller half of the brace. Use 2 of the supplied 6 x 16mm bolts to connect brace to the support rods. (Fig 5)
- 10) Repeat steps 6, 7 and 8 for the right side brace.
- 12) Reconnect all hoses and tighten clamps.
- 13) Install radiator shrouds and plastic louvers.
- 14) Fasten the radiator shrouds to the radiators using the supplied 6x25mm hex head bolts with the supplied washers and supplied spacers (Fig 6 & 7)
- 15) Re-fill radiator coolant.