

Pit Bull Spools Fitting Chart

Revised 3/7/18

APRILIA

RS 250	6MM	
RSV MILLE	6MM	
TUONO	6MM	
FALCO	6MM*	* REQUIRES FALCO SPACERS
RSV4	6MM	

ANY SPOOLED MODELS NOT LISTED WILL USE 6MM SPOOLS

BMW

S1000RR	8MM W/ 3MM SPACER	
S1000R	8MM W/ 3MM SPACER	
HP4	8MM W/ 3MM SPACER	
S1000SX	8MM W/ 3MM SPACER	

ANY MODELS NOT LISTED WILL NOT USE SPOOLS

BUELL

1125R ('09 & up)	6MM	Delrin/Plastic spools recommended on all Buell/EBR bikes. Use of a stand using factory spools can damage your swingarms.
1190 RS	6MM	
1190 RX	6MM	
ANY SPOOLED MODELS NOT LISTED WILL USE 6MM SPOOLS		

DUCATI		
749 ('05 & up)	8MM	
851, 888	Factory, welded on	
821 Monster	6MM W/ 3MM SPACER	
899/959 PANIGALE	6MM W/ 3MM SPACER	
900 Monster (thru mid '01)	Factory, welded on	
999 ('05 & up)	8MM	
999R	8MM	
Multistrada Enduro 1200	8MM W/ 15MM SPACER	
ANY MODELS NOT LISTED WILL NOT USE SPOOLS		

HONDA

RS125 '95 & on	8MM	
RC51 '00,'02 & on	8MM	
RC51 '01	No spools	
CBR600RR	8MM	
CBR954RR	8MM	
CBR1000RR	8MM	
ANY MODELS NOT LISTED WILL NOT USE SPOOLS		

KAWASAKI

EX250 (up to '07)	No spools	
Ninja 250/300 ('08 & up)	10MM	
Ninja 400	8MM w/ 0.135" spacer	
ZX6R ('95 - '97)	12MM	
ZX6R/ZX6RR ('98 - '12)	10MM	
ZX6R ('13 - '17)	8MM	
ZZR600	10MM	
Ninja 650R (up to '16)	10MM	
Ninja 650R / Z650 ('17)	8MM	
Versys 650(up to '12)	10MM	
Versys 650('13 and up)	8MM	
Vulcan 650	10MM	
ZX7R (All)	12MM	
Z800	8MM W/ 3MM SPACER**	**Remove before riding
Z900	8MM W/ 3MM SPACER	
Z900RS	8MM W/ 15MM SPACER	**Remove before riding

ZX9R (up to '97)	12MM	
ZX9R('98 & on)	10MM	
ZX10R (up to '10)	10MM	
ZX10R ('11-'17)	8MM	
ZRX1100/ZRX1200	10MM	
ZX12/ZX14	10MM	
Ninja 1000/Z1000 (up to '13)	10MM*	*do not use delrin
Ninja 1000/Z1000 ('14 & up)	8MM*	*do not use delrin

KTM		
RC390 / Duke 390	10MM	
690 Duke	10MM x 1.5 (KTM THREAD PITCH)	
990 Superduke	10MM x 1.5 (KTM THREAD PITCH)	
RC8R	10MM x 1.5 (KTM THREAD PITCH)	

SUZUKI		
Any and all Suzuki bikes that have spooled swingarms, use 8mm (8MM) spools. There are no exceptions as of the date of this update. We will update the fitting chart if this changes in the future.		
GSX250R	8MM	
500 Gamma	8MM	
RF600R/RF900R	8MM	
GSXR600	8MM	
SV650	8MM	
GSXR750	8MM	

GSXR1000 ('01 & on)	8MM	
SV1000	8MM	
TL1000S/TL1000R	8MM	
GSXR1100	8MM	
GSXR1300 Hayabusa	8MM	
B King	8MM	

TRIUMPH

Daytona 675 (up to '10)	6MM	2012-2013 Triumphs have size inconsistencies. If M8, order 8MM W/ 15MM SPACER. If M6 order 6MM
Daytona 675 ('11-'12)	8MM	
Daytona 675 ('13 & up)	8MM W/ 15MM SPACER	
Street Triple 675 (up to '10)	6MM	
Street Triple 675 ('11-'12)	8MM	
Street Triple 675 ('13 & up)	8MM W/ 15MM SPACER	
Street Triple 765	8MM W/ 15MM SPACER	
Tiger 800/800XC	8MM W/ 15MM SPACER	
Thruxton R ('16)	8MM	
Bobber ('17)	8MM W/ 15MM SPACER	

ANY MODELS NOT LISTED WILL NOT USE SPOOLS

YAMAHA

TZ250	10MM	
TZR250	10MM	
R3	6MM	

FZR400 ('90 Only)	10MM	
FZR400/600/1000 (exc. '90 FZR400)	No spools	
YZF600(all)/SECA II	No spools	
R6 ('99 & up)	6MM	
R6S ('06 -'09)	6MM	
YZF750/YZF1000 (ex R1)	10MM	
FZ8	6MM	
FZ-09	6MM	
FZ1('01 & up)	No spools	
R1 ('98 & up)	6MM	
FZ10 ('16 & up)	6MM	
V-MAX ('09 & up)	6MM	
ANY MODELS NOT LISTED WILL NOT USE SPOOLS		