



Installation Instructions 60-0502LC
2013-18 Triumph Daytona 675 Stator Cover Protector

- 1) Attach the skid plate to the Woodcraft cover protector by bolting it from the inside. **IMPORTANT - Use BLUE THREADLOCKING COMPOUND** on the skid plate mounting bolts. Coat the threads completely and allow the thread locking compound to fully set before use.
- 2) Confirm the 60-2500 rubber pad is adhered to the matching pocket on the back side of the cover.
- 3) Install the Woodcraft cover over the OEM cover:
 - a) Remove the four stock bolts in the mounting points where cover protector will be.
 - b) Place the aluminum black spacer (04-SP50257125) in-between the cover protector and OEM cover.
 - c) Install mounting hardware (04-SC665Z) in the four locations shown at the right through the cover protector and spacers as shown in top photo.
- 4) Start the motorcycle and inspect for any leaks before riding.



WARNING

Installation of Woodcraft Billet Covers involves removal and reinstallation of certain factory components such as fasteners, alternator stators and oil-retention gaskets. **FAILURE TO INSTALL THESE COMPONENTS IN COMPLIANCE WITH ALL SPECIFIC INSTRUCTIONS SUPPLIED WITH BILLET COVER KIT, MAY CAUSE OIL LOSS OR DAMAGE TO ENGINE RESULTING IN LOSS OF CONTROL OF MOTORCYCLE AND SERIOUS INJURY OR DEATH.**