

www.GRAVESPORT.com

Toll Free: 800-867-6480 Fax: 818-

Fax: 818-902-3821

7629 Densmore Avenue Van Nuys, Ca. 91406

FSY-14FZ09-xx

Frame Sliders Yamaha FZ-09 (2014)

PARTS LIST

Hex Bolt (M10 x 1.25P x 90mm)	1
Hex Bolt (M10 x 1.25P x 100mm)	1
Washers	2
Aluminum Spacer Long-Left	1
Aluminum Spacers Short-Right	1
Delrin Pucks	2

<<<<< THIS PRODUCT SHOULD BE INSTALLED BY A QUALIFIED TECHNICIAN >>>>>

The two aluminum spacers each have one end the same length when the shoulders are lined up. That end goes into the puck. **(photo 1)**



PHOTO 1

 Remove the bolt and washer from the left side forward motor mount, above the exhaust ports. (photo 2)



РНОТО 2

- 2) Place the washer onto the 100mm hex bolt. Slide the bolt and washer through the puck.
- 3) Slide the spacer onto the bolt. (The long side goes into the puck. The short side goes into the frame).

4) Apply a thread locking compound onto the threads of the bolt. Place the frame slider assembly into the vacated hole and torque to 45Nm / 33 ft. lbs. (photo 3)



PHOTO 3

- Repeat steps 2 through 5 on the right side. Using the 90MM hex bolt.
- 6) When installing the frame slider bolt on the right side make sure the threaded hole on the engine is lined up properly.
- 7) Periodically check the torque of the bolts.