



## Bar End Installation Instructions

---

### **MADE IN THE USA!**

### **Carefully read instructions in their entirety before the install**

Professional installation is recommended. Always use proper safety measures during the install of this product. Do not try to install this product without proper tools, recently calibrated torque wrench, correct torque specifications from **factory service manual**, safety goggles and gloves. The motorcycle must be in a fixed secure position before the install process begins. **Shogun is not responsible for any part of your motorcycle for any reason.**

- Remove OEM bar end.
- Install Shogun bar end.
- Check to make sure you have proper clearance between the bar end and grip. Make sure throttle side operates smooth. Some manufactures have OEM inserts such as some Suzuki models, use these inserts in conjunction with the Shogun bar ends.

If you have any questions please call and we can assist over the phone.



### **READ CAREFULLY**

Shogun cannot guarantee that they will protect your motorcycle from any extent of damage. Shogun frame sliders are really meant to help possibly save the frame from damage in the event of a crash. Because Shogun frame slider products have been successful in saving cases, bodywork, levers and so on in the past, customers just assume sometimes you can put the product on and no damage will happen. The fact is, some crashes result in little or no damage to the motorcycle and some bikes are destroyed. It's kind of like a bumper on a car sometimes it works sometimes it doesn't, it really depends on all the different forces applied during the incident. We've seen bikes crash at 100 mph with little damage and some at 15 mph with major damage.