

www.GRAVESPORT.com

Toll Free: 800-867-6480 Fax: 818-902-3821

7629 Densmore Avenue Van Nuys, Ca. 91406

EXY-15R1-SOM

Moto 1 Cat-Back Exhaust Yamaha R1 2015

PARTS LIST

Moto1 Slip On-SilencerClamp1

<><<INSTALLATION OF THIS PRODUCT SHOULD BE PERFORMED BY A QUALIFIED TECHNICIAN >>>> <<<<<PLEASE READ INSTRUCTIONS CAREFULLY BEFORE BEGINNING INSTALLATION >>>>>>

- 1) Remove the clamp at the catalytic converter.
- 2) Remove the allen bolt at the top of the stock muffler which attaches at the foot peg mount. Keep this bolt for installation of the Graves Moto1 Slip-On
- 3) Remove the stock muffler by sliding it straight back off the catalytic converter. Also remove the gasket and gasket retainer. They will not be reinstalled with the Graves Moto1 Slip-On.
- 4) Slide the Graves Moto1 Slip-On onto the catalytic converter leaving the clamp loose. Align the top mounting tab to the foot peg. Using the stock allen bolt, tighten the mounting tab to the foot peg mount then tighten the lower clamp.

WARNING

Be sure to wipe any dirt or finger prints off your new Graves Moto1 Slip-On with a soft clean towel and mild cleaner or WD-40 before starting your engine. Failure to remove any dirt or residue will result in stains and finger prints being permanently burnt into the surface of the titanium.