



## FILLER PANEL LIGHTS FOR 23-UP HARLEY-DAVIDSON

- WARNING** This indication alerts you to the fact that ignoring the contents described herein can result in potential serious injury or death if not followed.
- CAUTION** This indication alerts you to the fact that ignoring the contents described herein can or will result in material damage and/or personal injury.
- ATTENTION** This indication alerts you to the fact that if you ignore this detail you will affect the performance or functionality of the product.

All Ciro products are designed for "easy assembly" and/or "plug and play". We recommend a competent mechanic install our products, using standard mechanical procedures to assure a safe and successful installation. Read completely and understand the instructions prior to starting installation.

NOTE: Ciro products are designed and manufactured under very strict quality control. Ciro warrants that products sold to the original purchaser shall be free from any defects in materials and workmanship for a period of 3 (three) years from the date of purchase, and a limited lifetime warranty against LED failure. Ciro will have no obligation if the customer cannot show proof of purchase. Warranty will not be granted unless the part is properly installed, unmodified and maintained. Ciro will not be liable for any consequential and incidental damages, including labor, or non-Ciro products. Please visit [Ciro3d.com](http://Ciro3d.com) for our complete warranty policy.



**Included Items**

1. Park on a level surface and shut off the motorcycle. Ensure that the engine has time to cool before installation. Cover areas of motorcycle around work area to protect surfaces from damage.
2. Remove the seat and saddlebags per your owner's manual and set aside.
3. Using a 7/16" socket, remove three nuts indicated in Fig. 1 and set aside. Remove the wiring plug from the light shown in Fig. 2.
4. Remove all screws from the fender bracket. You will reuse the three screws shown in Fig. 2.
5. Place bracket on new light with original screws and provided washers and tighten securely. Fig. 3
6. Reinstall light and bracket back onto fender with the three nuts previously removed and tighten securely. Connect plug into new light receptacle and turn on motorcycle to test and understand functionality of the light. The light will have run, turn and brake functions. Fig. 4
7. To make use of the previously installed Lightstrike COMMANDER you need to install the provided two pin wire extension. Plug the two pin end to the receptacle shown in Fig. 5 and follow the existing harness along the fender line and behind the frame and up into the underseat area. Secure with provided cable ties. Fig. 6
8. Since this is the right side of the motorcycle, plug the wire into one of the plugs with a brown wrap as in Fig. 7. The left side will have a purple indicator. If plugs are full from other lights unplug one and use the provided y-splitter.
9. Repeat steps 3-8 on other side of the motorcycle and replace saddlebags and seat.



