

Assembly Instructions

Model:	KL650F/G/H
Description:	Top Case Bracket
Part Number:	99994-1495
Flat Rate Time(Hr):	0.1

Before you begin, read through these instructions and check that all parts are present. Please note that Kawasaki cannot assume any responsibility for damage resulting from incorrect installation.


Kawasaki recommends that all genuine accessories should be fitted by an authorized Kawasaki dealer.

The following symbol indicates the information for proper installation and operation in this instruction.

• Indicates a procedural step or work to be done.


Refer to the following Service Manual for detailed procedures. (KL650F/G/H) P/No.: 99830-0066-01 or 99832-0201-01

	Parts List						
No.	Component Name	Part No.	Qty	Remark			
1	Bracket	11057-7099	1				
2	Bracket	11057-7100	1				
3	Bolt	130BA0510	4				



Installation Instructions

- Remove the carrier (Refer to the Service Manual).
- Install the brackets [1] [2] on the carrier [A].
- Tighten the bolts [3].



• Install the carrier (Refer to the Service Manual).

Basic Torque for General Fasteners

The table below, relating tightening torque to thread diameter, lists the basic torque for the bolts and nuts. Use this table for only the bolts and nuts which do not require a specific torque value. All of the values are for use with dry solvent-cleaned threads.

Threads dia (mm)	Torque			
Threads dia. (mm)	N·m	kgf⋅m	ft·lb	
5	3.4 ~ 4.9	0.35 ~ 0.50	30 ~ 43 in·lb	
6	5.9 ~ 7 .8	0.60 ~ 0.80	52 ~ 69 in·lb	
8	14 ~ 19	1.4 ~ 1.9	10 ~ 13.5	
10	25 ~ 34	2.6 ~ 3.5	19 ~ 25	
12	44 ~ 61	4.5 ~ 6.2	33 ~ 45	
14	73 ~ 98	7.4 ~ 10.0	54 ~ 7 2	
16	115 ~ 155	11.5 ~ 16.0	83 ~ 115	
18	165 ~ 225	17.0 ~ 23.0	125 ~ 165	
20	225 ~ 325	23.0 ~ 33.0	165 ~ 240	

Check tightness of all fasteners in regular interval. Retighten loose fasteners.