

CENTER BRACKET

Accessory Name	Parts Number	Application Model	Issue Date	Publication No.
CENTER BRACKET	08L70-K2E-A10	CT125A	May 2023	MII 17936

Introduction

ALL INFORMATION, ILLUSTRATIONS, DIRECTIONS AND SPECIFICATIONS INCLUDED IN THIS PUBLICATION ARE BASED ON THE LATEST PRODUCT INFORMATION AVAILABLE AT THE TIME OF APPROVAL FOR PRINTING. Honda Motor Co., Ltd. RESERVES THE RIGHT TO MAKE CHANGES AT ANY TIME WITHOUT NOTICE AND WITHOUT INCURRING ANY OBLIGATION WHATSOEVER. NO PART OF THIS PUBLICATION MAY BE REPRODUCED WITHOUT WRITTEN PERMISSION. THIS MANUAL IS WRITTEN FOR PERSONS WHO HAVE ACQUIRED BASIC KNOWLEDGE OF MAINTENANCE ON HONDA MOTORCYCLES, MOTOR SCOOTERS, ATVS or SXS.

Honda Dealer:

Please give a copy of these instructions to your customer.

Customer

Because this accessory requires specialized knowledge, special tools and equipment, it is recommended to only install it at a dealer with qualified technicians.

How To Read These Symbols

Your safety, and the safety of others, is very important. To help you make informed decisions we have provided safety messages and other information throughout this manual.

Number 1 WARNING You CAN be KILLED or SERIOUSLY HURT if you don't follow instructions.

CAUTION You CAN be HURT if you don't follow instructions.

MOTICE The purpose of this message is to help prevent damage to your vehicle, other property, or the environment.

NOTE Things you want to know, things that are useful to know.

Follow the instructions of the Service Manual.

Follow the other symbol instructions of the "Basic Shop Manual".

Other Instruction Symbols

The symbols used throughout these instructions show specific "Warnings and Notices".

Refer to the "Basic Shop Manual" for the description of each symbol.

INFORMATION

ACAUTION

To prevent burns, allow the engine, exhaust system, radiator, etc., to cool before installing the accessory.

NOTICE

· Take care not to damage the painted surfaces of the motorcycle.

NOTE:

Save all removed parts unless otherwise indicated.

PARTS LIST

When the instruction manual and the installation instructions are included in this kit, be sure to give them to the customer.

< CENTER BRACKET >

Component	No.	Parts Name	Qty	Parts No.
	(1)	Center bracket	1	-
(1)	(2)	Center bracket collar	2	-
(3) —	(3)	Screw	1	90130-MJE-D40
	(4)	Socket bolt	2	-
	(5)	Hex wrench	1	-
(2)				

MAXIMUM LOADING CAPACITY

• The weight of the cargo must not exceed the following maximum loading capacity:

Maximum Loading Capacity		
Center bracket	2.2 lb (1.0 kg)	

TORQUE INFORMATION

ITEM	N·m (kgf·m)			
Screw	10 Nm (1.0 kgf-m)			
Socket bolt	21 Nm (2.1 kgf-m)			

Refer to the Service Manual for the torque values including standard torque of the removed parts. (III)

INSTALLATION

