




SENA
MOTORCYCLE BLUETOOTH®
COMMUNICATION SYSTEM
WITH MESH INTERCOM™

HD SPEAKERS

1.0.1

QUICK START GUIDE

ENGLISH

RIDE CONNECTED

Designed for those who want a sleeker device, the 50R Mesh Intercom™ headset continues Sena's affinity for advancing adventure and keeping people connected on the road.

- Mesh Intercom™ up to 2 km (1.2 miles)*
- Bluetooth® 5.0
- Audio Multitasking™
- HD Speakers
- Intercom up to 2 km (1.2 miles)*
- Multi-Way Intercom
- Multi-Language Voice Command
 - Support Siri and Google Assistant

* in open terrain

GETTING STARTED

- This product comes with a Quick Start Guide, which is a basic version of the User's Guide. A **FULL VERSION OF THE USER'S GUIDE CAN BE DOWNLOADED AT SENA.COM**.
- Update this product for free with the latest firmware to fully enjoy the new advanced features built into this product. Visit sena.com to see how to update your product.
- Users can follow Sena on Facebook, YouTube, Twitter and Instagram to receive the most up to date information on products, helpful tips and all other announcements regarding Sena products.

SENA Sena Technologies, Inc.
sena.com
Customer Support: support.sena.com

SENA QUICK START GUIDE


GETTING STARTED

How to Use This Guide

The legend and callouts are here to help you read the illustrations. New technology can be confusing, but we've created a simple way to perform actions using illustrations.



Buttons



GETTING STARTED

Icon Legend

- Tap button the specified number of times
- Press and Hold button for the specified amount of time
- Audible prompt

QUICK START GUIDE

SENA QUICK START GUIDE


GETTING STARTED

How to Use This Guide

The legend and callouts are here to help you read the illustrations. New technology can be confusing, but we've created a simple way to perform actions using illustrations.



Buttons




GETTING STARTED

SENA QUICK START GUIDE


GETTING STARTED

Installation


Using the Hook and Loop Fasteners for Main Unit



Using the Double Sided Adhesive Tapes for Main Unit




Using the Clamp for Main Unit




QUICK START GUIDE

Installing the Speakers and the Microphone



Mesh Intercom Antenna

Pull the Mesh Intercom Antenna inwards slightly to unfold it.



QUICK START GUIDE

Sena 50 Utility App

By simply pairing your phone with your headset, you can use the **Sena 50 Utility App** for quicker and easier set up and management.

- App Features
 - Mesh Intercom, Bluetooth Intercom, Music, Device settings, Quick Start Guide, and User's Guide.
- Download
 - Android: Google Play Store > "Sena 50 Utility"
 - iOS: App Store > "Sena 50 Utility"



Sena Device Manager

The **Sena Device Manager** allows you to upgrade the firmware and configure its settings directly from your PC or Apple computer. Download the **Sena Device Manager** from sena.com.

QUICK START GUIDE


Basic Operations

- Powering On**
 - = (HOLD 1s)
- Powering Off**
 - = (TAP 1x)
- Volume Up**
 - = (TAP 1x)
- Volume Down**
 - = (TAP 1x)

Checking the Battery Level

Instructions are for when powering the headset on.


Visual Method



QUICK START GUIDE

Phone Pairing

Mobile Phone Pairing
Press and hold the **Center Button** and **(+) Button** for 3 seconds when the 50R is turned off.



QUICK START GUIDE

Mobile Phone

- Answer a Call**
 - = (TAP 1x)
- End a Call**
 - = (HOLD 2s)
- Reject a call**
 - = (HOLD 2s)

Siri and Google Assistant

Activate the Siri or Google Assistant Installed on Your Smartphone

QUICK START GUIDE

Music Controls

- Play/Pause**
 - = (HOLD 1s)
- Track forward**
 - = (HOLD 1s)
- Track backward**
 - = (HOLD 1s)

Mesh Intercom™

When **Mesh Intercom** is enabled, the 50R will automatically connect to nearby 50R users and allow them to talk to each other by pressing the **Mesh Intercom Button**.

- Mesh Intercom On**
 - = (HOLD 1x)
- Mesh Intercom Off**
 - = (HOLD 1x)

"Mesh intercom on"

"Mesh intercom off"

QUICK START GUIDE

Open Mesh™

When **Mesh Intercom** is enabled, the headset will be in **Open Mesh** (default: channel 1) initially. Users can freely communicate with each other in the same **Open Mesh** channel.

Channel Setting (Default: channel 1)

If the **Open Mesh** communication experiences interference because other groups are also using **channel 1** (default), change the channel. You can select from channels 1 to 9.

QUICK START GUIDE

Enter into the Channel Setting

- = (HOLD 2x)
- "Channel setting, 1"
- Navigate between Channels**
 - (1) → 2 → ... → 8 → 9 → Exit → 1 → ...
 - = (TAP 1x) or = (TAP 1x)
 - "#"
- Save the Channel**
 - = (TAP 1x)
 - "Channel is set, channel #"

Note: To exit the channel setting, tap the **(+) Button** or **(-) Button** until you hear a voice prompt, "Exit", and tap the **Center Button**.

QUICK START GUIDE

Group Mesh™

Group Mesh is a closed group intercom function that allows users to join, leave, or rejoin a group intercom conversation without pairing each headset. Up to 24 users can all be connected in each private group.

Creating a Group Mesh

Creating a **Group Mesh** requires **two or more Open Mesh** users.

1. Enter into **Mesh Grouping** to create a **Group Mesh**.

2. The headsets complete **Mesh Grouping** and automatically switch from **Open Mesh** to **Group Mesh**.

Joining an Existing Group Mesh

One of the members in an **Existing Group Mesh** can allow new members in **Open Mesh** to join the **Existing Group Mesh**.

QUICK START GUIDE

Mesh Grouping

- One of the **current members** and a **new member** enter into **Mesh Grouping** to join the **Existing Group Mesh**.
 - and = (HOLD 5s)
 - "Mesh Grouping"
- The headsets complete **Mesh Grouping**. The new members will hear a voice prompt as their headsets automatically switch from **Open Mesh** to **Group Mesh**.
 - "Group Mesh"

QUICK START GUIDE

Reset Mesh

If a headset in an **Open Mesh** or **Group Mesh** resets the **Mesh**, it will automatically return to **Open Mesh** (default: channel 1).

Enable/Disable Mic (Default: Enable)

Users can enable/disable the microphone when communicating in a **Mesh Intercom**.

- Enable/Disable the Microphone**
 - = (HOLD 1s)

QUICK START GUIDE

Bluetooth Intercom

Up to three other people can be paired with the headset for **Bluetooth intercom** conversations.

- Intercom Pairing**
 - = (HOLD 5s)
 - "Intercom Pairing"

The 50R will automatically pair with a Sena headset. Flashing blue LED confirms intercoms are paired.

Note: Repeat the step above to pair with Intercom Friends C & D.

QUICK START GUIDE

Two-Way Intercom

- Last-Come, First-Served**
 - = (HOLD 1x)
- Start/End with Intercom Friend 1**
 - = (TAP 1x)
- Start/End with Intercom Friend 2**
 - = (TAP 2x)
- Start/End with Intercom Friend 3**
 - = (TAP 3x)

QUICK START GUIDE

FM Radio

- FM Radio On**
 - = (HOLD 1s)
- FM Radio Off**
 - = (HOLD 1s)
- Scan Stations**
 - = (HOLD 1s)
- Seek Stations**
 - = (TAP 2x)

Navigating Preset Stations

- = (TAP 1s)

QUICK START GUIDE

Configuration Menu

- Accessing the Headset Configuration Menu**
 - = (HOLD 10s)
 - "Configuration menu"
- Executing Menu Options**
 - = (TAP 1x)
- Navigating Between Menu Options**
 - = (TAP 1x)
 - "Menu prompt"

Troubleshooting

- Factory Reset**
 - = (HOLD 10s)
 - = (TAP 2x)
 - = (TAP 1x)
- Fault Reset**
 - = (TAP 1x)

Note: Fault Reset will not restore the headset to factory default settings.

QUICK REFERENCE

TYPE	OPERATION	BUTTON COMMANDS
Basic Operations	Power on / Power off	(HOLD 1s)
	Volume up / Volume down	(TAP 1x) or (TAP 1x)
	Answer phone call	(TAP 1x)

Mobile Phone	End phone call	(HOLD 2s)
	Reject phone call	(HOLD 2s)
	Speed dial	(HOLD 3s)

Siri and Google Assistant	Activate the Siri or Google Assistant	(HOLD 3s)
	Play/Pause music	(HOLD 1s)
	Track forward	(HOLD 1s)

Music	Track backward	(HOLD 1s)
	FM radio on/off	(HOLD 1s)
	Select preset	(HOLD 1s)

FM Radio	Seek forward/backward	(TAP 2x) or (TAP 2x)
	Scan up FM band/ stop scanning	(HOLD 1s)

Mesh Intercom™	Mesh Intercom on/off	(HOLD 1x)
	Channel setting	(HOLD 2x)
	Mesh Grouping	(HOLD 5s)

Intercom	Reset Mesh	(HOLD 8s)
	Enable/Disable Mic	(HOLD 1s)
	Intercom pairing	(HOLD 5s)

Intercom	Start/End intercom	(HOLD 1x)
----------	--------------------	-----------