



Assembly Instructions

Description:	Gel Seat	Model:	VN1700 Nomad & Voyager
Part Number:	K53001-217 (Pillow-top, with GEL front seat) K53001-218 (Pillow-top, with GEL passenger seat)	Estimated Assembly Time:	15 min.

Before you begin installation, read through the installation instructions and check to be sure all parts are present.

If you are in doubt as to any part of the installation, please ask your authorized Kawasaki dealer to complete the installation. Please note that Kawasaki cannot assume any responsibility for damage resulting from incorrect installation.

Parts List				Tools Required
Seq.	Part Number	Description	Qty.	■ 10mm wrench ■ Owner's Manual ■ <i>Other tools may be required depending upon the accessories fitted to your motorcycle</i>
1. -or-	K53001-217 K53001-218	Seat	1	

Installation Instructions

Installing the Gel Seat on the motorcycle

- Remove the motorcycle's original rider and passenger seats (see the vehicle's Owner's Manual for seat removal information).
- Remove the flange nuts from the threaded studs on the Gel Seat. These nuts will not be reused as they are for seat protection during shipping.
- Remove the nuts and the metal seat brackets from the motorcycle's original seat and install the brackets to the Gel Seat using the original nuts. Tighten the nuts securely.
- Remove the rubber bumpers from the motorcycle's original seat and install them into the Gel Seat.

NOTE:

- **When removing and installing the rubber bumpers in the seat, use a light lubricant (or soapy water) and a twisting motion to remove or set the bumpers into the holes in the seat base.**
- Remove the nuts and washers from the motorcycle's passenger seat hand-hold straps. To mount the supplied strap, transfer the nuts and the washers to the new passenger Gel Seat strap studs and tighten the hardware securely.
- Install the new, accessory Gel Seats onto the motorcycle in reverse order of the original seat's removal (refer to the vehicle's Owner's Manual for seat installation information).

NOTE:

- **Clean the Gel Seat and/or the Backrest Pad with a soft, damp cloth. Do not use hard, abrasive cleaners.**