



INSTALLATION

V-SHIELD HORN COVER—BLACK

7204

PARTS INCLUDED

- 1 V-Shield Horn Cover—Black
- 1 Offset Mount
- 1 Horn Mounting Bracket
- 2 5/16"—18 Acorn Nuts — Chrome
- 2 5/16" Flat Washers
- 2 5/16" Split Lock Washers
- 1 5/16"—18 x 1-1/4" Hex Head Cap Screw — Chrome
- 1 Installation Instructions

Please read and understand entire instructions before starting installation.

THANK YOU FOR CHOOSING KÜRYAKYN!

IN ORDER TO PROTECT YOU AND OTHERS FROM POSSIBLE INJURY AND/OR PROPERTY DAMAGE OR LOSS, PLEASE PAY CLOSE ATTENTION TO ALL INSTRUCTIONS, WARNINGS, CAUTIONS AND ATTENTION NOTES REGARDING THE USE AND CARE OF THIS PRODUCT.

WARNING! THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN CAN RESULT IN POTENTIAL DEATH OR SERIOUS INJURY.

ATTENTION! This indication alerts you to the fact that ignoring the contents described herein may negatively affect product performance and functionality.

CAUTION! This indication alerts you to the fact that ignoring the contents described herein can result in potential injury or material damage.

TOOLS SUGGESTED

Socket Set with Ratchet, 10mm Wrench

STRICTLY OBSERVE THE FOLLOWING GUIDELINES IN ORDER TO USE THE PRODUCT PROPERLY AND AVOID POTENTIALLY DANGEROUS ACCIDENTS.

STEP 1

Read and understand all steps in the instructions before starting the installation. Park the motorcycle on a hard, level surface and turn off the ignition. Let cool.

NOTE: Harley-Davidson® has used horns from a variety of suppliers. This cover is compatible with stock horns using a M6 stud to attach it to the original equipment mount bracket. Any other style of horn may require modification to the bracket supplied.

WARNING! YOU WILL BE WORKING AROUND THE ENGINE AND EXHAUST SYSTEM DURING INSTALLATION. ENSURE THAT THE ENGINE AND EXHAUST SYSTEM HAVE FULLY COOLED TO PREVENT INJURY.

CUSTOMER SERVICE

877.370.3604 (toll free)

INSTALLATION QUESTIONS

techsupport@kuryakyn.com
or call 715.247.2983

LIMITED WARRANTY

Küryakyn warrants that any Küryakyn products sold hereunder, shall be free of defects in materials and workmanship for a period of one (1) year from the date of purchase by the consumer excepting the following provisions:

- Küryakyn shall have no obligation in the event the customer is unable to provide a receipt showing the date the customer purchased the product(s).
- The product must be properly installed, maintained and operated under normal conditions.
- Küryakyn makes no warranty, expressed or implied, with respect to any gold plated products.
- Küryakyn shall not be liable for any consequential and incidental damages, including labor and paint, resulting from failure of a Küryakyn product, failure to deliver, delay in delivery, delivery in nonconforming condition, or for any breach of contract or duty between Küryakyn and a customer.
- Küryakyn products are often intended for use in specific applications. Küryakyn makes no warranty if a Küryakyn product is used in applications other than intended.
- Küryakyn electrical products are warranted for one (1) year from the date of purchase by the consumer. L.E.D.'S contained in components of Küryakyn products will be warranted for defects in materials and workmanship for 3 years from the date of purchase where as all other components shall be warranted for one(1) year. This includes, but is not limited to; control modules, wiring, chrome & other components.

- Küryakyn makes no warranty of any kind in regard to other manufacturer's products distributed by Küryakyn. Küryakyn will pass on all warranties made by the manufacturer and where possible, will expedite the claim on behalf of the customer, but ultimately, responsibility for disposition of the warranty claim lies with the manufacturer.

ABOUT OUR CATALOG

For purchasing Küryakyn® products, you can receive a complete catalog free of charge.

Send the Proof-of-Purchase below with your address to: Küryakyn, P.O. Box 339, Somerset, WI 54025.

Please indicate either Accessories Catalog for Harley-Davidson® or GL & Metric Cruisers.

Be sure to ask your local dealer about other Küryakyn® products, the motorcycle parts and accessories designed for riders by riders.

©2005 Küryakyn USA® All Rights reserved.

-cont.-

7204-21HD-0711

kuryakyn.com



STEP 2 Remove the acorn nut that attaches the stock horn to the rubber mount on the motorcycle. Unplug the wires from the back of the horn and remove the horn. PIC 1

STEP 3 Remove the M6 nut that secures the horn to the stock mount and cover. Set this nut aside, it will be reused. Remove the horn from the stock cover.

STEP 4 Insert the 5/16"-18 x 1-1/4" Hex Head Cap Screw from the back side of the Offset Bracket, the head of the bolt will index into a hex-shaped cutout on the back of the Offset Bracket. Install the offset mount over the stock rubber mount and secure it loosely with a 5/16" Acorn Nut, Flat Washer and Split Lock Washer. Adjust the position of the offset mount to approximately 5 o'clock (this will center the horn and cover assembly between the cylinders) and tighten the Acorn Nut. FIG 1

STEP 5 Attach the horn with its stock M6 nut to the supplied mounting bracket as shown. PIC 2




STEP 6 Slide the horn/bracket assembly and the chrome cover onto the exposed threads of the 5/16" Hex Head Cap Screw. Secure with the 5/16" Acorn Nut, Flat Washer, and Split Lock Washer. FIG 1

STEP 7 Reconnect the horn wires and verify its operation.

CAUTION! On fuel injected models, be certain that the horn cover or its mounting components do not come in contact with the fuel lines. Remember to take engine movement under consideration on rubber mount models. Reposition the cover as necessary.

ATTENTION! It is the installer's responsibility to ensure that all of the fasteners (including pre-assembled) are tightened before operation of the motorcycle. Küryakyn will not issue a warranty on components lost due to improper installation. Periodic maintenance may be required.

ATTENTION! Secure all wiring away from any moving parts, pinch points or extreme heat. Küryakyn WILL NOT issue a warranty on any electrical component that fails due to pinched, crimped, broken, abraded, melted or frayed wires.



Ride On!

PAGE
2

V-SHIELD HORN COVER—BLACK

INSTALLATION