

# **[POWER] COMMANDER III**

CERTIFIED **USB**

## **2006-2008 Honda VFR800 VTEC** Installation Instructions

### **Parts List**

- 1 Power Commander
- 1 USB Cable
- 1 CD-ROM
- 1 Installation Guide
- 1 Power Adapter
- 2 Power Commander Decals
- 2 Dynojet Decals
- 2 O2 eliminators
- 2 Velcro® Strip
- 1 Alcohol Swab


**The ignition MUST be turned OFF before installation!**

You can also download the Power Commander software and latest maps from our web site at:


**[www.powercommander.com](http://www.powercommander.com)**




**PLEASE READ ALL DIRECTIONS BEFORE STARTING INSTALLATION**




- 1 Remove the main seat.
- 2 Remove the front two fuel tank mounting bolts.
- 3 Prop the front of the fuel tank up.
- 4 Locate the throttle body wiring harness connector (Fig. A). This connector is located on the right hand side of the bike under the right, rear corner of the air box.
- 5 Unplug the connector shown in Fig. A.



- 6 Plug the connectors from the PCIII in-line of the stock wiring harness (Fig. B).




- 7 Route the PCIII wiring along the inside of the frame towards the rear of the bike (Fig. C).



- 8 Route the ground wire from the PCIII harness under the frame towards the battery. Attach ground wire from PCIII to the NEGATIVE terminal of the battery (Fig. D).



- 9 Install the PCIII in the rear section of the trunk using the supplied velcro (Fig. E). Make sure to clean both surfaces first with alcohol.
- 10 Remove the left hand side fairing.



- 11 Locate the stock O2 sensor connections (Fig. F). Unplug both the front and rear exhaust O2 sensors.
- 12 Plug the Dynojet O2 eliminators into the stock wiring harness in place of the stock O2 sensors.
- The stock O2 sensors no longer need to be connected to anything.*
- 13 Reinstall the fairing, fuel tank, and seat.