

Input Voltage	Flood Cube Max Amperage	6" Driving Light Max Amperage
12V DC	3amp	0.4amp

Warranty and Disclaimer

Within THREE years after the purchase date, the original buyer may return any XKchrome controller that has failed due to a defect in materials or workmanship. Lights that have one or more LEDs fail to illuminate due to a defect in materials or workmanship are covered with a THREE year warranty for **the original buyer**.

Installation of this product must be performed by a licensed professional. Should the failure of the product be the result of damage occurring as a result of improper installation, alteration of the product or an act or omission on the part of the consumer, this warranty is void. XKGLOW Lighting shall not be responsible for any consequential damages which arise from the use and/or installation of the product. If the kit is installed in any manner other than specified, XKGLOW Lighting reserves the right to deny any warranty claims at the discretion of the technical support department. Any product return must include the original packaging, invoice number and a statement of the alleged defect. Upon receipt of the returned product, the company will test the product for defect. If the results of the testing do not support the warranty claim, do not reveal any defect or indicate consumer negligence in the installation and handling of the product, then the product will be returned to you and you will be charged a reshipping fee. If the product is returned from an address within the continental United States, within the first 30 days after purchase, and is found to be defective, XKGLOW Lighting will exchange or refund the original purchase expense. This offer does not extend to the cost for shipping charges on any international packages.

Additional Disclaimer Terms

Please check your local and state laws for the proper use of this product.

- Improper installation of electrical products such as lighting may cause damage to any vehicle or device to which the improperly handled or installed lighting is attached.
- Improperly installed product may cause electrical injury to persons.
- It is recommended that the kit should be installed by a licensed professional.
- XKGLOW assumes no liability for the installation of the product.
- Warranty or liability will not exceed the product purchase price, which shall be buyer's sole and exclusive remedy.

Return/Exchange Procedure

1. Email [xk@xkglow.com] to notify us of the product issue as well as the item number and name of customer on invoice.
2. We will send you the trouble-shooting guide to fix the issue, or to narrow down which of the component(s) need to be replaced. If the issue still exists, we will ask you to send back the defective items to be replaced.
3. Please send the returned item as instructed, along with claims and a telephone number where you can be reached.
4. After the returned item(s) have been accepted and inspected, we will issue a refund or replace the items ASAP. For refunds, item(s) must be sent to XKGLOW within 14 days from date of purchase. Original shipping charges are not refundable.

We always stand behind our products and are committed to our customers! For questions you may have, please contact xk@[xkglow.com](mailto:xk@xkglow.com). We normally respond within 24 hours. (Monday-Friday).

1. **Remove Number Plate:** Remove the number plate by undoing both rubber straps. Pull up on the number plate, fish the throttle and brake cable out, then disconnect the turn signals, headlight, and ignition.
2. **Remove OEM Headlight:** Remove the 2 torx head screws and twist the light out of the number plate.
3. **Install New Mount:** To install the mount, start the tab at the bottom of the number plate under the mounting plate and use your fingers to pry up on the OEM screw holes (**Figure 1**) to pop the plate into place. This will be a tight fit to ensure stability for the lights. Install the provided fasteners in the OEM screw locations (**FIGURE 1**), then install the provided self-tapping screw into the bottom of the plate (**FIGURE 2**).



FIGURE 1



FIGURE 2


4. **Install Lights into Plate:** Install the 6" Driving Light Bar into the mount first. Be sure the SAE logo is right side up. Install the provided spacers into the sides of the cube lights, then install the cube light into the mount. Only hand tighten both lights and temporarily mount it to the bike to adjust the angle height of both lights. Then take the number plate back off and finish tightening both lights. See **FIGURE 3**.



FIGURE 3

5. **Wiring Lights:** Connect the factory turn signals and ignition back to their OEM connectors. Then, plug the connector on the new harness to the OEM headlight connector. Connect the **BLUE** wire from the wire harness to the **RED** (positive) wire on the cube light. The **GREEN** wire from the wire harness will connect to the **RED** (positive) wire of the light bar. Connect the **BROWN** wire from the harness to both **BLACK** (ground) wires of the cube light and light bar. See **FIGURE 4** for wiring diagram.

FIGURE 4



- 6. Install Number Plate:** Fish the throttle and brake cables back through the number plate and push it down in the recessed mounts. Reattach the rubber straps on both sides. Bundle and zip tie wires as necessary. Be sure not to pinch any wires when putting the number plate back on.
- 7. Connecting RGB Controller (add-on):** If you have purchased the add-on RGB controller, see the listing instructions for XK065001-KIT on our website for information on installing the XKCHROME mini controller.

YOU MUST TEST FUNCTIONALITY OF BOTH LIGHTS BEFORE HITTING THE ROAD OR TRAIL!!



Please note: There are multiple XKGLOW apps on the App Store. Only the XKchrome App will work with the XKchrome Bluetooth Controller. The App icon is pictured here.